

Quick Start Guide

TC ELECTRONIC CORONA MINI CHORUS

Depth - Sets the intensity of the modulation effect.

Speed - Controls the speed of the modulation.

Output

Footswitch - Turns the effect on and off.

USB - Connect to your computer for firmware updates and TonePrint editing.

Power - Connect a 9V / >100 mA power supply.

FX Level - Sets the intensity of the effect.

Input



Visit tcelectronic.com to download the full manual

tc electronic