

# Quick Start Guide

## TC ELECTRONIC DITTO STEREO LOOPER

**USB** - Connects to your computer for firmware updates and transferring loops between your computer and the pedal.

**Toggle switch** - This switch performs the following functions:

- To store the current loop as a backing track, nudge the switch up.
- To delete the stored loop/backing track, hold the switch in the up position for 3 seconds.
- To set the level of the backing track, hold the switch in the down position while adjusting the loop level knob.


**Outputs**

**Footswitch** - Controls various looping functions. See the other side of this page for details.




**Power** - Connect a 9V / >100 mA power supply.

**Loop level** - Adjusts the volume of the looped audio.

**Inputs**



Visit [tcelectronic.com](http://tcelectronic.com) to download the full manual



**NOTE :** When the loop is clear, DITTO turns off and returns to true bypass