

Quick Start Guide

TC-HELICON MIC MECHANIC 2

Echo - Selects the type and amount of echo effect on your voice.

Reverb - Selects the type and amount of reverb effect on your voice.

USB - Accepts micro-USB cables for firmware updates.

On/Off



Correction - Adjusts the amount of pitch correction.

Tone - Engages 'Adaptive Tone' for EQ, compression, de-essing and gating. Hold the Tone button while turning the Correction knob to adjust the amount of Echo feedback.

Footswitch - Bypasses the echo, reverb and correction effects. Hold the footswitch for a few seconds to enter Tap Mode, then press the footswitch a few times in rhythm with your desired tempo.



Out - Connect to a mixer or powered speaker.

Mic - Connect your microphone.

Power - Connect a 9V / >300 mA power supply, such as the PowerPlug 9 (not included). The pedal also accepts 4 x AA batteries.

Visit tc-helicon.com to download the full manual

TC HELICON