

Quick Start Guide

TC ELECTRONIC SHAKER MINI VIBRATO

Depth - Controls the intensity of the vibrato effect.

Speed - Adjusts the speed of the vibrato effect.

Output

Footswitch - Turns the effect on and off.

USB - Connect to your computer for firmware updates and TonePrint editing.

Power - Connect a 9V / >100 mA power supply.

Ramp - Adjusts how quickly the effect ramps up after the effect is turned on.

Input



Visit tcelectronic.com to download the full manual

tc electronic