


# Quick Start Guide

## TC ELECTRONIC SPARK MINI BOOSTER

**Level** - Adjusts the level change when the booster is engaged.



**Power** - Connect a 9 V / > 100 mA power supply.

**Output**

**Input**

**Footswitch** - A quick press turns the pedal on and off.

**Tip:** Hold down footswitch to engage PrimeTime mode and release to disengage.

Visit [tcelectronic.com](http://tcelectronic.com) to download the full manual

**tc electronic**