

Quick Start Guide

TC ELECTRONIC VORTEX FLANGER

USB - Connects to your computer for firmware updates and TonePrint editing.

Power Input - Connect a 9V / >100 mA power supply.

Speed - Controls the speed of the flanger effect.

Depth - Controls the depth of the flanger sweep.

Feedback - Controls the intensity of the flanger effect.

Delay Time - Controls the pitch range of the flanger effect.

Output

Input

Footswitch - Turns the effect on and off.

Type - Choose between rich Flanger mode inspired by the classic SCF pedal, custom TonePrint setting and old-school Tape mode.



Visit tcelectronic.com to download the full manual