

Quick Start Guide

TC ELECTRONIC VORTEX MINI FLANGER

Depth - Controls the intensity of the effect.

Speed - Adjusts the speed of the flanger effect.

Output

Footswitch - Turns the effect on and off.

USB - Connect to your computer for firmware updates and TonePrint editing.

Power - Connect a 9V / >100 mA power supply.

Feedback - Adjusts the amount of modulated signal that is fed back into the pedal, controlling the intensity of the effect.

Input



Visit tcelectronic.com to download the full manual

tc electronic